

ACS Export

Lenel S2

LenelS2 (S2 NetBox / NetBox Extreme / Global — on-prem or hosted)

1. **Scope the data:** activity log (events), alarms, threat levels, and audit log.
2. **Confirm access path:** S2 web UI (Reports).
3. **Pick an export method:**
 - a. *S2 Reports module.* Reports → Activity / Alarm / Person / Access Level / Audit → set 30-day window → Export to CSV or Excel.
4. **Run the export:** consistent time zone (S2 typically logs in the controller's local TZ), include node and portal IDs for joins.
5. **Normalize:** per-resource CSVs or a multi-tab .xlsx.
6. **Sanity-check:** activity row counts against the web UI's Activity view for the same window.